Installation instructions for the Leica M10

Firmware 2.6.5.0

Dear Customers,

Installing the firmware 2.6.5.0 on your Leica M10 will add additional functions and improve performance to your camera.

Update Contents

Model Number	LEICA M10
Update Version	2.6.5.0
Update Filename	M10-2.6.5.0-CUSTOMER.FW

Overview

Version	Description

Version	**Performance Improvements:**
2.6.5.0	
	➢ **NEW: Compatible with the new Leica FOTOS app** Connect your smartphone to your Leica camera
	➢ **NEW: QR Code for all Leica Cameras** Easy pairing of smartphone and Leica cameras.
	➢ **NEW: 1-Click Connection with FN-Button** WLAN starts without submenus on FN-button.
	➢ **NEW: Fixed WLAN name and password** No submenus for setting name and password.
	➢ **NEW: No submenus for mode settings** No submenus for setting a connection mode.

Please follow these steps to install the new firmware for your Leica M camera:

Recharge the battery to 100% and insert the battery into the camera.

1. Download the new firmware file to your computer.
2. Prepare the SD card for installation:

    a. Please make sure that the card contains at least 200 MB of free disk space.
    b. It is recommended to format the card inside the camera before continuing.
    c. Download the new firmware file to your computer.
    d. Copy the firmware file to the root directory of the SD card.
    e. Eject the SD card properly from your computer.

3. Insert the SD card into the camera and switch the camera on.
4. Go to Main Menu / Camera Information / Camera Firmware
5. Press "Yes" to confirm and start the process;

    a. You should save your current profiles to the SD card before proceeding with the update.
    b. Wait until the update installation is completed.
    c. Restart the camera, do not eject the SD card.
    d. Please load your last saved profiles from the SD card after the first startup.

6. The update process is complete.

CAUTION:

Please do **NOT** turn off your camera, remove the Battery, or remove the SD Memory Card while the update is running.

DISREGARDING THIS WARNING CAN CAUSE SERIOUS DAMAGE TO YOUR CAMERA!