Installation instructions for the LEICA M
(M Typ 240 / M-P Typ 240 / M-E Typ 240)

Firmware 2.0.6.0

Dear Customers,
Installing the latest firmware on your Leica M Typ 240 will improve the performance and reliability of your camera.

File Description

Modellnummer	LEICA M Typ 240 (M Typ 240 / M-P Typ 240 / M-E Typ 240)
Updateversion	2.0.6.0
Name der Update-Datei	M_240-2.0.6.0-CUSTOMER.FW

Overview

Version	Description
2.0.6.0	• **General bug fixing**

Instructions for updating the LEICA M firmware

1. Format an SD memory card in your Leica M.
2. Turn off the camera and insert the card into an SD card reader – either integrated or connected to your computer. (A reader is required for Firmware updates).
3. Download the Firmware file from the Leica M site using the “DOWNLOAD” link.
4. Save the file M_240-2.0.6.0-CUSTOMER.FW at the top level of the card’s folder structure.
5. Remove the card properly from your card reader, insert the card into the camera and close the bottom cover.
6. Press the “INFO” button and hold it, simultaneously turn on the camera using the main switch.
7. The update process takes 2-4 minutes. “Loading file…” appears on the screen.
8. When the update is done, a corresponding message appears on the screen.

   The Message disappears after some seconds.

Note: When installing the new Firmware version, all user profiles will be deleted and need to be set again after the new firmware is installed. We recommend taking note of the specific settings before updating.

If the battery does not have sufficient charge, you will see a corresponding warning message

CAUTION:

Please do **NOT** turn off your camera, remove the Battery, or remove the SD Memory Card while the update is running.

DISREGARDING THIS WARNING CAN CAUSE SERIOUS DAMAGE TO YOUR CAMERA!