



Installation Guide for Leica X2 Firmware Update 1.1

Dear customer,

Installing the new firmware version will enable you to optimize the functions of the Leica X2 in a variety of ways.

Update features

Model, designation	LEICA X2
Update version	Version 1.1
File name	X2-1_100.zip (unzipped: X2-1_100.upd)

Version	Description
Version 1.1	1. Improved noise as from ISO 1600 2. Improved automatic white balancing 3. General improvements and performance optimization

Firmware update process

- Step 1: Fully charge the camera's battery.
- Step 2: Format an SD memory card in your LEICA X2.
- Step 3: Download the firmware update file 'X2-1_100.zip'. double-click on the file to unzip it.
- Step 4: Copy the unzipped firmware update file X2-1_100.upd to the root folder level of the SD memory card.
- Step 5: Make sure the camera is switched off.
- Step 6: Insert the charged battery in the camera. If the battery is not fully charged, the update menu will not be displayed.
- Step 7: Insert the memory card prepared as per step 2-4 in the camera.
- Step 8: Switch the camera back on by the main switch, while holding down the INFO button.
- Step 9: Confirm that you want to update the camera's firmware to version 1.1. When the update has completed successfully, you are prompted to restart the camera by the main switch: Switch the camera off and back on.
- Step 10: Format the SD memory card in your LEICA X2 again to be sure the firmware update file has been deleted.

IMPORTANT POINTS:

_ Leica recommends updating the firmware version in your camera if the current firmware is older than the latest available version.

_ It is not necessary to update the firmware if version 1.1 is already installed in the camera.

_ When you format the SD memory card, all the data on it – including protected files – will be deleted and cannot be recovered. Please back up your data to an alternative storage device (such as a PC or external hard disk) to make sure you do not lose anything important.

_ Do **not** switch your camera off, and do **not** take the memory card out while the firmware update is in progress.

FAILURE TO FOLLOW THESE INSTRUCTIONS MAY RESULT IN SERIOUS DAMAGE TO YOUR CAMERA!