



Installation instructions for the Leica T (Typ 701) - **Firmware 1.8**

Dear Customers,

by installing the firmware 1.8 on your Leica T (Typ 701) you will gain additional functions and performance for your camera.

Update Contents

Model Number	LEICA T (Typ 701)
Update Version	Version 1.8
Update File Name	T701_180.TUF

Description

Version	Description
1.8	<u>Performance Improvements:</u> ➤ Simplified pairing process between camera and smartphone/APP ➤ Improvement of Color Aberration for all TL lenses ➤ 100% support including auto update of the new TL 2.8/18mm lens

Firmware Update Procedure

1. Download an updated version of the firmware.
2. Copy the firmware file onto a SD Memory Card in its top level folder.
3. Make sure to turn off the power switch on the camera.
4. Insert the fully charged battery to the body. If the battery is not fully charged, the update process screen will not appear.
5. Insert the SD Memory Card into the camera.
6. Turn the camera – while simultaneously pressing the video release button – on.
7. The firmware update screen will appear. Press OK.
8. The LEICA T will start the update process. The firmware update will take about 90 seconds.
9. After the update process please restart the camera.

CAUTION:

Please do **not** turn off your camera, or do **not** remove the SD Memory Card, do **not** remove the lens while updating your camera's firmware. **DOING SO CAN CAUSE A SERIOUS DAMAGE TO YOUR CAMERA!**