



## Installation instructions for Leica CL - Firmware 2.0

Dear Customer,

by installing the firmware 2.0 on your Leica CL you will gain additional functions and performance for your camera.

### Update Contents

<b>Model</b>	LEICA CL
<b>Update Version</b>	Version 2.0
<b>Update File Name</b>	CL___20_.lfu

### Description

Version	Description
2.0	<p><b><u>Performance Improvements:</u></b></p> <ul style="list-style-type: none"><li>➤ <b>NEW MENU ITEM: Double dial customization</b> Swap functions between dials for each PASM mode enabled</li><li>➤ <b>Button and Dial lock</b> Long push of left dial button lock causes lock for all buttons and dials except from Power Switch, Release Button and Left Dial Button long push.</li><li>➤ <b>NEW MENU ITEM: Power Saving Mode implemented</b> The camera automatically goes to Auto Power Off after 10s.</li><li>➤ <b>Touch AF field navigation with EVF usage</b> In Touch AF Mode whilst using EVF, the cursor keys can move the AF Field/AFs, Spot/AFs.</li></ul>

### Firmware Update Prozess

1. Copy the firmware file onto a SD Memory Card in its top level folder.
2. Make sure to turn off the power switch on the camera.
3. Insert the fully charged battery to the body. If the battery is not fully charged, the update process screen will not appear.
4. Insert the SD Memory Card into the camera.
5. Choose MENU / Main Menu / Camera Information / Firmware
6. Press "Start Update" and confirm the start process.
7. The camera will guide you through the backup process of your personal settings.

8. Wait until this process is finished.
9. Restart your camera; do not remove the SD card.
10. Confirm the upload of your personal settings from the SD card.

**CAUTION:**

Please do **not** turn off your camera, or do **not** remove the SD Memory Card, do **not** remove the lens while updating your camera's firmware.

**DOING SO CAN CAUSE A SERIOUS DAMAGE TO YOUR CAMERA!**